



THE BEAUTIFUL STONE LOOK YOU WANT. — SIMPLIFIED. —

AUTHENTIC STONE SIDING EASIER THAN EVER

With WayPost Stone Siding, you get the authentic, natural stone look you want with easy installation that saves time and money. No special tools are required and it can be installed year round. Finally, you get all the texture and color you want with fast and simple installation. That's the beauty of WayPost. Welcome to the new stone age.

WayPost
Stone Siding

BY BOULDER CREEK STONE



WHY USE WAYPOST STONE SIDING?

- **WINTER WON'T SLOW YOU DOWN.** Save time and money by avoiding building and heating shelters. WayPost is easily installed in any weather.
- **IT'S EASY TO CUT.** Custom fitting WayPost Stone Siding couldn't be easier, all you need is a circular saw and tin snips.
- **IT'S MAINTENANCE-FREE.** No sealers required. Just hose it down twice a year.
- **EASY DIY INSTALLATION.** You don't need to be an accomplished mason to create a gorgeous stone look – just a few basic tools, like the ones in your tool box.
- **WATER INTRUSION IS NEVER A PROBLEM.** WayPost's integral drainage plane is designed to eliminate water and give you peace of mind.
- **LOOKS GREAT INSIDE, TOO.** WayPost is the perfect accent for fireplaces, interior archways, walls and more.



AVAILABLE ACCESSORIES:

- ① Chisel Face Sills
- ② Inside Corner Trim
- ③ Outside Corner Pieces

Outlet Trim:



To order call 763-780-9114 or visit waypoststonesiding.com

MODERN STAK



Merlot: SS100

With a hint of dark red and burgundy, this dynamic profile utilizes the straight lines of stacked stone to create unique texture and beautiful shadows.



Chablis: SS120

The rugged, natural and authentic appearance of dry stacked stone provides a dramatic texture and visually appealing design.



Pinot: SS110

Full bold textures and rich colors inspired by nature create a warm and inviting look, making it the favorite profile of architects and installers.



Flat Panel

All flat panels are 32" wide x 9" high x 1"-2" thick.

CLASSIC LEDGE



Ash Gray: SS210

Deep tones of ash accompanied by aged sand accents provide character and depth, offering a wide array of application options.



Burlywood Tan: SS220

With its light brown tones and randomized dark accents, this unique and authentic color pattern adds an extra sense of style to your home.



Aero Gray: SS200

A refined rustic nature with soft warm gray tones enhance the architectural features of not just the exterior of your home but the interior as well.



Interlocking Corner Panels

Corner panels come in varying widths and are 9" high x 1"-2" thick.

EASY INSTALLATION

INSTALLATION 101

1. **INSTALL STARTER STRIP** - Place at the bottom of where the stone is to be applied. Provides a level, solid base for the stone siding installation.
2. **ATTACH WEATHER RESISTIVE BARRIER** (for exterior installations) - We recommend 2 layers of grade D building paper or 15# felt (check local building codes).
3. **INSTALL STUCCO STOP** (if needed) - Stucco stop should be used around windows, doors, and vertical transitions.
4. **ATTACH PLASTIC LATH** (if needed) - A plastic lath is required for projects using outlet trim pieces, sill pieces under windows, or for stone siding ending at a soffit.
5. **INSTALL ACCESSORIES** (if needed) - Using construction adhesive, apply outlet trim pieces or sill pieces under windows.
6. **INSTALL INSIDE CORNER TRIM** - Level the inside corner piece and ensure all inside corner pieces are flush with each other.
7. **INSTALL OUTSIDE CORNER PIECES** - Starting from the outside corners, begin installing corner panels.
8. **INSTALL FLAT PANELS** - Begin at the bottom along an edge, screwing through the holes in the clips on the stone panels into the wall, hitting as many studs as possible. Continue staggering the pieces to avoid having the vertical piece end line up with the course below.
9. **FINAL ROW OR SILL PIECES** - If your project ends at a soffit you will need to cut pieces to height and glue onto the wall. If you are ending with sill pieces, screw these into place at the top of your stone the same way you did with the flat panels.

TOOLS NEEDED

- Screw Gun
- Hammer Tacker with Staples
- Tape Measure
- Pencil
- Level
- Saw with Masonry or Diamond Blade
- Tin Snips
- Utility Knife
- Caulk Gun
- Protective Eyewear
- Protective Dust Mask

INSTALLATION DETAILS



- ① Plastic Lath
- ② Flashing
- ③ Chisel Face Sill
- ④ Sheathing
- ⑤ House Wrap
- ⑥ Weather Resistive Barrier
- ⑦ WayPost Stone Siding
- ⑧ Pan Head Screw

Visit waypoststonesiding.com to download complete installation instructions and to view our instructional installation video.

8282 Arthur St NE
Minneapolis, MN 55432

WayPost
Stone Siding

BY BOULDER CREEK STONE

waypoststonesiding.com
763-780-9114